EDS/EFS/DSD/DS (M90, M96) CONTROL STATIONS REPLACEMENTS PARTS

ITEM	DESCRIPTION	USED ON	PART NO.
3A	COMPLETE COVER ASSEMBLY	EFS/EDS11271, 11272, 21271, 21272	DS672
	(Less contacts—includes cam and cover screws—not shown)	EFS/EDS31271, 31272	
		DSD923, DSD924, DS672	
		EFS/EDS11273, 11274, 21273, 21274	DS673
		EFS/EDS31273, 31274	
		DSD925, DSD926, DS673	
		EFS/EDS11275, 21275, 31275	DS675
		DSD927, DS675	
3B	COMPLETE COVER ASSEMBLY – S634	EDS11273, 11274, 21273, 21274	DS673-S634
	(Includes handle, shaft, bushing, operating cam module	EDS31273, 31274	
	and hardware—not shown, less contacts)	DSD925, DSD926, DS673	
		EDS11275, 21275, 31275, DSD927, DS675	DS675-S634
3C	COMPLETE COVER ASSEMBLY – S635	EDS11273, 11274, 21273, 21274	DS673-S635
	(Includes handle, shaft, bushing, operating cam module	EDS31273, 31274	
	and hardware—not shown, less contacts)	DSD925, DSD926, DS673	
		EDS11275, 21275, 31275, DSD927, DS675	DS673-S635
4	PUSHBUTTON CONTACT BLOCK ASSEMBLY	2- OR 3-POSITION/2-CIRCUIT	ED11
	(Includes mounting strap)	2- OR 3-POSITION/4-CIRCUIT	ED12
5	REPLACEMENT CONTACT BLOCK	ALL EDS/EFS/DSD	ESWP126*

* Note: Four circuit units require (2) ESWP126 contact blocks.